

## aLOKSAK® Zip-Lock Instructions

### To Open:

1. Gently separate zip-lock opening beginning at the center using forefingers and thumbs.
2. Place valuables inside aLOKSAK bags according to size.
3. DO NOT OVERSTUFF BAGS.

### To Close:

1. Evacuate as much air as possible from bags.
2. Press zip-lock seal together beginning at one edge of the bag and slowly slide thumb and forefinger along the full length of the opening.
3. Repeat at least twice to ensure positive closure.



## VERY IMPORTANT aLOKSAK® Bags are waterproof only if sealed as follows:

To test bag prior to use, trap a small amount of air inside the bag. Seal zip-lock completely by sliding fingers from one end to the other being certain there are no kinks or bends in the seal. The zip-lock seal should feel smooth and wrinkle-free.

Submerge bag in a container of water and squeeze sides gently to test seal. If air bubbles appear, the bag is damaged or not sealed properly. Repeat the test to verify if the bag is damaged. If defective and unused, contact LOKSAK, INC. @ <http://www.loksak.com> for instructions on how to return the defective bag for replacement.

**Caution:** Leak-proof bags are durable but not indestructible. Normal wear is not a defect. DO NOT ATTEMPT TO REPLACE THE aLOKSAK WITH A COMMERCIAL, OVER-THE-COUNTER, RECLOSEABLE BAG. aLOKSAK bags have a unique closure system that holds three patents and has been certified leak-proof to 200 feet/60 meters by SSI / National Association of Scuba Diving Schools. These bags have been tested by the US Navy Experimental Diving Unit and are approved for diving applications.

**Replace the bags after extended use.  
Avoid over exposure to extreme heat**

## Splash Pak™ Pouch Instructions:

- 1) Place your packed and sealed aLOKSAK bags inside the Splash Pak Sport™ pouch.
- 2) Tighten draw string at opening just enough to secure articles.
- 3) Adjust waistband to desired length. Pull clasp away from skin and clothing and snap clasp together.
- 4) To release, squeeze top and bottom release buttons on clasp and pull apart.

### Hands-Free Waterproof Protection for Your Valuables

**PROTECT ELECTRONIC DEVICES**, important documents, keys, and more from water, sand, and dirt.

Splash Pak Sport™ features aLOKSAK bags certified waterproof to 60 meters/200 feet by Scuba Schools International and tested and approved by the U.S. Navy Experimental Diving Unit. aLOKSAK bags have a patented leak-proof/airtight seal.

# Splash pak Sport<sup>Leilan's Island</sup>

全ての使用方法に注意深く従って下さい。

使用する前に全ての説明をお読み下さい。

## アロックサックバッグ説明書

開け方：

1. ジップロックを中心部から親指と人差し指を使ってそっと開けて下さい。
2. 袋のサイズに合った貴重品をアロックサックバッグに入れて下さい。
3. バッグの中に入れ過ぎないように注意して下さい。

閉め方：

1. バッグからできるだけ空気を出して下さい。
2. ジップロックのシールをバッグの端から閉め始め、ゆっくりと親指と人差し指で開いている口の長さ全部にわたってすべるように動かして下さい。
3. きちんと閉まっているのを確かめるため少なくとも 2 回繰り返して下さい。

## 大変重要

**アロックサックバッグは以下のように密閉されれば防水となります：**

ご使用の前にバッグをテストするために少しの空気をバッグの中に入れて下さい。指を一端から別の端まで滑らして、シールがよじれてないか曲がってないかを確認してジップロックを完全に閉めて下さい。ジップロックのシールはスムーズでシワがないようにして下さい。

密閉をテストするためにバッグを水の入った容器の中に入れてそっと両側を押し絞るようにして下さい。もし空気が出ましたら、バッグはダメージを受けているか密閉されていないかのどちらかです。バッグがダメージを受けてないかを確認するためテストを繰り返して下さい。もし欠陥があり未使用の場合は、欠陥のある商品を交換するために返品の方について **LOKSAK, INC. @ <http://www.loksak.com>** に連絡して下さい。

**注意：** 漏れないバッグは丈夫ですがこわれないものではありません。通常の消耗は欠陥ではありません。アロックサックバッグを商業用に市販されている再密閉可能なバッグの代わりに使用しないで下さい。アロックサックバッグは 3 件の特許を持った独特な密閉方式であり、SSI / 全国スキューバダイビング学校協会により水深 200 フィート/60 メートルまでの防水を保証されています。これらのバッグは米国海軍実験潜水班によってテストされ潜水向けの使用に認可されています。

## スブラッシュバックスポーツ™使用書：

- 1) ものを入れて密閉したアロックサックバッグをスブラッシュバックスポーツ™ポーチの中に入れてください。
- 2) モノが動かない程度に開き口の紐を締めて下さい。
- 3) ウエストバンドの長さをお好みの長さに調節してください。留め金具をポーチの外側から引き出しカチッと締めて下さい。
- 4) 留め金を外す時は、上部と下部を挟みつけ金具上のボタンを外し引っ張り離して下さい。  
あなたの貴重品のためのハンズフリーな防水保護

あなたの貴重品のためのハンズフリーな防水保護

電子機器、重要書類、鍵、その他もろもろを、水、砂、ほこりから保護して下さい。

スブラッシュバックスポーツ™は、国際的なスキューバスクールから水深 60 メートル/200 フィートまでの防水を保証され、米国海軍実験潜水班によりテストされ認可されたアロックサックバッグが付いています。アロックサックバッグは特許を得た漏れ防止/密閉方式です。